

## **Installation of IV Pole adapter**

- 1. On the back of the Millennium absorber there are two round openings that are approximately  $\frac{3}{4}$ " in diameter. Install the IV pole adapter into the opening that has two small threaded holes on the side.**
- 2. Install the two small set screws included with your kit into the two threaded holes. These screws will hold the IV pole adapter in place.**
- 3. Insert the IV pole into the adapter and place it at the desired height and position. Tighten the two screws in the adapter to hold the IV pole in place.**